



- Safe isolation between coil and contacts per DIN EN 50178
- A separator plate (e.g., 209-191) must be used for voltages greater than 250 V between adjacent relay modules and for safe isolation.
- Inductive loads have to be attenuated by an appropriate protective circuit in order to protect relay coils and contacts.

[illegible]

Accessories see pages 50 ... 55

[illegible]